

# **Operation and Safety Manual**

Original Instructions - Keep this manual with the machine at all times.

Boom Lift Models E450A E450AJ M450AJ S/N 0300208529\* to Present

\*See inside front cover for exceptions.



**3121713** June 29, 2018 - Rev C This manual also covers the following Serial Numbers.

0300202268

0300202273

# 

Operating, servicing and maintaining this vehicle or equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle or equipment in a well-ventilated area and wear gloves or wash your hands frequently when servicing. For more information go to www.P65Warnings.ca.gov.

# FOREWORD

This manual is a very important tool! Keep it with the machine at all times.

The purpose of this manual is to provide owners, users, operators, lessors, and lessees with the precautions and operating procedures essential for the safe and proper machine operation for its intended purpose.

Due to continuous product improvements, JLG Industries, Inc. reserves the right to make specification changes without prior notification. Contact JLG Industries, Inc. for updated information.

# SAFETY ALERT SYMBOLS AND SAFETY SIGNAL WORDS



This is the Safety Alert Symbol. It is used to alert you to the potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death



INDICATES AN IMMINENTLY HAZARDOUS SITUATION. IF NOT AVOIDED, <u>WILL</u> RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE A RED BACK-GROUND.



INDICATES A POTENTIALLY HAZARDOUS SITUATION. IF NOT AVOIDED, <u>MAY</u> RESULT IN MINOR OR MODERATE INJURY. IT MAY ALSO ALERT AGAINST UNSAFE PRACTICES. THIS DECAL WILL HAVE A YELLOW BACKGROUND.



INDICATES A POTENTIALLY HAZARDOUS SITUATION. IF NOT AVOIDED, <u>COULD</u> RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE AN ORANGE BACK-GROUND.

# NOTICE

INDICATES INFORMATION OR A COMPANY POLICY THAT RELATES DIRECTLY OR INDI-RECTLY TO THE SAFETY OF PERSONNEL OR PROTECTION OF PROPERTY.

# **WARNING**

THIS PRODUCT MUST COMPLY WITH ALL SAFETY RELATED BULLETINS. CONTACT JLG INDUSTRIES, INC. OR THE LOCAL AUTHORIZED JLG REPRESENTATIVE FOR INFORMA-TION REGARDING SAFETY-RELATED BULLETINS WHICH MAY HAVE BEEN ISSUED FOR THIS PRODUCT.

# NOTICE

JLG INDUSTRIES, INC. SENDS SAFETY RELATED BULLETINS TO THE OWNER OF RECORD OF THIS MACHINE. CONTACT JLG INDUSTRIES, INC. TO ENSURE THAT THE CURRENT OWNER RECORDS ARE UPDATED AND ACCURATE.

# NOTICE

JLG INDUSTRIES, INC. MUST BE NOTIFIED IMMEDIATELY IN ALL INSTANCES WHERE JLG PRODUCTS HAVE BEEN INVOLVED IN AN ACCIDENT INVOLVING BODILY INJURY OR DEATH OF PERSONNEL OR WHEN SUBSTANTIAL DAMAGE HAS OCCURRED TO PER-SONAL PROPERTY OR THE JLG PRODUCT.

#### For:

- Accident Reporting
- Product Safety Publications
- Current Owner Updates
- Questions Regarding
  Product Safety

#### **Contact:**

Product Safety and Reliability Department JLG Industries, Inc. 13224 Fountainhead Plaza Hagerstown, MD 21742 USA

or Your Local JLG Office (See addresses on rear cover)

## In USA:

Toll Free: 877-JLG-SAFE (877-554-7233)

## **Outside USA:**

Phone:	240-420-2661
Fax:	301-745-3713
E-mail:	ProductSafety@JLG.com

- Standards and Regulations
  Compliance Information
- Questions Regarding Special Product Applications
- Questions Regarding Product Modifications

# **REVISION LOG**

- Original Issue A July 6, 2015
- Revised B May 30, 2018
- Revised C June 29, 2018 Revised Covers, Prop 65

#### SECTION - PARAGRAPH, SUBJECT

**SECTION - 1 - SAFETY PRECAUTIONS** 

1.1	GENERAL 1-1
1.2	PRE-OPERATION1-1
	Operator Training and Knowledge
	Workplace Inspection1-2
	Machine Inspection1-3
1.3	OPERATION
	General
	Trip and Fall Hazards1-4
	Electrocution Hazards1-5
	Tipping Hazards 1-7
	Crushing and Collision Hazards
1.4	TOWING, LIFTING, AND HAULING
1.5	MAINTENANCE1-11
	Maintenance Hazards 1-11
	Battery Hazards 1-13

# SECTION - 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

2.1	PERSONNEL TRAINING2-1
	Operator Training2-1
	Training Supervision 2-1
	Operator Responsibility2-1
2.2	PREPARATION, INSPECTION, AND MAINTENANCE 2-2
	Pre-Start Inspection2-4
	Function Check2-5

#### PAGE SECTION - PARAGRAPH, SUBJECT

SkyGuard Function Test	2-7
General	2-10

#### SECTION - 3 - MACHINE CONTROLS AND INDICATORS

3.1	GENERAL	-1
3.2	CONTROLS AND INDICATORS	-1
	Ground Control Console	-2
	Platform Control Console	-6
	Platform Control Indicator Panel	3

#### **SECTION - 4 - MACHINE OPERATION**

4.1	DESCRIPTION
4.2	BOOM OPERATING CHARACTERISTICS AND
	LIMITATIONS 4-1
	Capacities 4-1
	Stability
4.3	MOTOR OPERATION
	Power/Emergency Stop4-2
	Platform/Ground Select Switch
	Motor Activation 4-5
4.4	TRAVELING (DRIVING)
	Traveling Forward and Reverse
	Traveling on a Grade4-8
4.5	STEERING
4.6	PLATFORM
	Loading From Ground Level

#### SECTION - PARAGRAPH, SUBJECT

	Loading From Positions Above Ground Level 4-9
	Platform Level Adjustment4-10
	Platform Rotation4-10
4.7	BOOM
	Swinging the Boom4-11
	Raising and Lowering the Lower and Mid Boom 4-11
	Raising and Lowering the Upper Boom
4.8	GENERATOR
	Automatic Operating Mode
	Battery Only Operating Mode
	Manual (Charge) Operating Mode
4.9	INVERTER
4.10	MACHINE FUNCTION SPEEDS
4.11	MACHINE SAFETY SYSTEM OVERRIDE (MSSO)
	(CE ONLY)
4.12	SKYGUARD OPERATION
4.13	BOOM SYNCHRONIZING PROCEDURE
4.14	SHUT DOWN AND PARK
4.15	MACHINE LIFTING AND TIE DOWN
	Lifting
	Tie Down

SECTION	PAGE	
SECTION -	5 - EMERGENCY PROCEDURES	
5.1	GENERAL	5-1
5.2	INCIDENT NOTIFICATION	5-1
5.3	EMERGENCY OPERATION	5-1
	Operator Unable to Control Machine	5-1
	Platform or Boom Caught Overhead	5-2
5.4	EMERGENCY TOWING PROCEDURES	5-2
5.5	MANUAL DESCENT SYSTEM	5-2
5.6	MANUAL SWING OVERRIDE	5-2
5.7	MACHINE SAFETY SYSTEM OVERRIDE (MSSO)	
	(CE ONLY)	5-3

#### SECTION - 6 - ACCESSORIES

PAGE

SOFT TOUCH
FALL ARREST PLATFORM
PIPE RACKS
Safety Precautions6-4
Preparation and Inspection
Operation

PAGE PAGE SECTION - PARAGRAPH, SUBJECT SECTION - PARAGRAPH, SUBJECT SECTION - 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE 7.1 7.2 Torque Specifications......7-4 Hydraulic Oil ......7-4 Critical Stability Weights ......7-6 7.3 7.4 Battery Maintenance, Quarterly ..... 7-15 75 Wheel Replacement ...... 7-18 7.6

#### **SECTION - 8 - INSPECTION AND REPAIR LOG**

SECTION - PARAGRAPH, SUBJECT

This Page Left Blank Intentionally

<b>FIGURE N</b>	UMBER - TITLE PAGE	FIGURE NUMBER - TITLE	PAGE
2-1.	Basic Nomenclature2-8		
2-2.	Daily Walk-Around Inspection - Sheet 1 of 32-9		
2-3.	Daily Walk-Around Inspection - Sheet 2 of 32-10		
2-4.	Daily Walk-Around Inspection - Sheet 3 of 32-11		
3-1.	Ground Control Console		
3-2.	Platform Console		
3-3.	Platform Control Indicator Panel		
4-1.	Position of Least Forward Stability		
4-2.	Position of Least Backward Stability4-4		
4-3.	Grade and Side Slopes4-7		
4-4.	Traveling on a Grade 4-8		
4-5.	Lifting Chart4-16		
4-6.	Decal Installation - Sheet 1 of 64-17		
4-7.	Decal Installation - Sheet 2 of 64-18		
4-8.	Decal Installation - Sheet 3 of 64-19		
4-9.	Decal Installation - Sheet 4 of 64-20		
4-10.	Decal Installation - Sheet 5 of 64-21		
4-11.	Decal Installation - Sheet 6 of 64-22		
6-1.	Soft Touch6-2		
7-1.	Serial Number Locations7-6		
7-2.	E450 Maintenance & Lubrication Diagram7-7		
7-3.	M450 Maintenance & Lubrication Diagram7-8		

LIST OF FIGURES

**FIGURE NUMBER - TITLE** 

#### PAGE FIGURE NUMBER - TITLE

PAGE

This Page Left Blank Intentionally

TABLE NU	IMBER - TITLE PAGE	TABLE NUMBER - TITLE	PAGE
1-1	Minimum Approach Distances (M.A.D.)		
1-2	Beaufort Scale (For Reference Only)1-9		
2-1	Inspection and Maintenance Table		
3-1	Simultaneous Functions3-12		
4-1	Skyguard Function Table4-14		
4-2	E450A/E450AJ Decal Legend4-23		
4-3	M450AJ Decal Legend4-29		
6-1	Available Accessories6-1		
7-1	Operating Specifications7-1		
7-2	Capacities		
7-3	Tire Specifications7-3		
7-4	Dimensional Data7-3		
7-5	Torque Requirements7-4		
7-6	Hydraulic Oil		
7-7	Mobil DTE 10 Excel 15 Specs7-5		
7-8	Mobil EAL 224H Specs7-5		
7-9	Critical Stability Weights7-6		
7-10	Lubrication Specifications7-9		
7-11	Wheel Torque Chart7-19		
8-1	Inspection and Repair Log8-1		

LIST OF TABLES

**TABLE NUMBER - TITLE** 

#### PAGE TABLE NUMBER - TITLE

PAGE

This Page Left Blank Intentionally

# **SECTION 1. SAFETY PRECAUTIONS**

### 1.1 GENERAL

This section outlines the necessary precautions for proper and safe machine usage and maintenance. It is mandatory that a daily routine is established based on the content of this manual to promote proper machine usage. A maintenance program, using the information provided in this manual and the Service and Maintenance Manual, must also be established by a qualified person and must be followed to ensure that the machine is safe to operate.

The owner/user/operator/lessor/lessee of the machine must not accept operating responsibility until this manual has been read, training is accomplished, and operation of the machine has been completed under the supervision of an experienced and qualified operator.

This section contains the responsibilities of the owner, user, operator, lessor, and lessee concerning safety, training, inspection, maintenance, application, and operation. If there are any questions with regard to safety, training, inspection, maintenance, application, and operation, please contact JLG Industries, Inc. ("JLG").


# 

FAILURE TO COMPLY WITH THE SAFETY PRECAUTIONS LISTED IN THIS MANUAL COULD RESULT IN MACHINE DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

## 1.2 PRE-OPERATION

## **Operator Training and Knowledge**

• The Operation and Safety Manual must be read and understood in its entirety before operating the machine. For clarification, questions, or additional information regarding any portions of this manual, contact JLG Industries, Inc.



- An operator must not accept operating responsibilities until adequate training has been given by competent and authorized persons.
- Allow only those authorized and qualified personnel to operate the machine who have demonstrated that they understand the safe and proper operation and maintenance of the unit.
- Read, understand, and obey all DANGERS, WARNINGS, CAU-TIONS, and operating instructions on the machine and in this manual.
- Ensure that the machine is to be used in a manner which is within the scope of its intended application as determined by JLG.
- All operating personnel must be familiar with the emergency controls and emergency operation of the machine as specified in this manual.
- Read, understand, and obey all applicable employer, local, and governmental regulations as they pertain to your utilization and application of the machine.

# **Workplace Inspection**

- Precautions to avoid all hazards in the work area must be taken by the user before and during operation of the machine.
- Do not operate or raise the platform from a position on trucks, trailers, railway cars, floating vessels, scaffolds or other equipment unless the application is approved in writing by JLG.
- Before operation, check work area for overhead hazards such as electric lines, bridge cranes, and other potential overhead obstructions.
- Check operating surfaces for holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards.
- Check the work area for hazardous locations. Do not operate the machine in hazardous environments unless approved for that purpose by JLG.
- Ensure that the ground conditions are adequate to support the maximum tire load indicated on the tire load decals located on the chassis adjacent to each wheel. Do not travel on unsupported surfaces.

# **Machine Inspection**

- Do not operate this machine until the inspections and functional checks as specified in Section 2 of this manual have been performed.
- Do not operate this machine until it has been serviced and maintained according to the maintenance and inspection requirements as specified in the machine's Service and Maintenance Manual.
- Ensure all safety devices are operating properly. Modification of these devices is a safety violation.

# **WARNING**

# MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.

- Do not operate any machine on which the safety or instruction placards or decals are missing or illegible.
- Check the machine for modifications to original components. Ensure that any modifications have been approved by JLG.
- Avoid accumulation of debris on platform floor. Keep mud, oil, grease, and other slippery substances from footwear and platform floor.

# 1.3 OPERATION

## General

- Machine operation requires your full attention. Bring the machine to a full stop before using any device, i.e. cell phones, two-way radios, etc. that will distract your attention from safely operating the machine.
- Do not use the machine for any purpose other than positioning personnel, their tools, and equipment.
- Before operation, the user must be familiar with the machine capabilities and operating characteristics of all functions.
- Never operate a malfunctioning machine. If a malfunction occurs, shut down the machine. Remove the unit from service and notify the proper authorities.
- Do not remove, modify, or disable any safety devices.
- Never slam a control switch or lever through neutral to an opposite direction. Always return switch to neutral and stop before moving the switch to the next function. Operate controls with slow and even pressure.
- Do not allow personnel to tamper with or operate the machine from the ground with personnel in the platform, except in an emergency.

- Do not carry materials directly on platform railing unless approved by JLG.
- When two or more persons are in the platform, the operator shall be responsible for all machine operations.
- Always ensure that power tools are properly stowed and never left hanging by their cord from the platform work area.
- When driving, always position boom over rear axle in line with the direction of travel. Remember, if boom is over the front axle, steer and drive functions will be reversed.
- Do not assist a stuck or disabled machine by pushing or pulling except by pulling at the chassis tie-down lugs.
- Fully lower platform and shut off all power before leaving machine.
- Remove all rings, watches, and jewelry when operating machine. Do not wear loose fitting clothing or long hair unrestrained which may become caught or entangled in equipment.
- Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

 Hydraulic cylinders are subject to thermal expansion and contraction. This may result in changes to the boom and/or platform position while the machine is stationary. Factors affecting thermal movement can include the length of time the machine will remain stationary, hydraulic oil temperature, ambient air temperature, and boom and platform position.

# **Trip and Fall Hazards**

• During operation, occupants in the platform must wear a full body harness with a lanyard attached to an authorized lanyard anchorage point. Attach only one (1) lanyard per lanyard anchorage point.



• Enter and exit only through gate area. Use extreme caution when entering or leaving platform. Ensure that the platform assembly is fully lowered. Face the machine when entering or leaving the platform. Always maintain "three point contact" with the machine, using two hands and one foot or two feet and one hand at all times during entry and exit.


• Before operating the machine, make sure all gates are closed and fastened in their proper position.

- Keep both feet firmly positioned on the platform floor at all times. Never position ladders, boxes, steps, planks, or similar items on unit to provide additional reach for any purpose.
- Keep oil, mud, and slippery substances cleaned from footwear and the platform floor.

# **Electrocution Hazards**

• This machine is not insulated and does not provide protection from contact or proximity to electrical current.





- Maintain distance from electrical lines, apparatus, or any energized (exposed or insulated) parts according to the Minimum Approach Distance (MAD) as shown in Table 1-1.
- Allow for machine movement and electrical line swaying.

Voltage Range (Phase to Phase)	MINIMUM APPROACH DISTANCE in Feet (Meters)						
0 to 50 KV	10(3)						
Over 50KV to 200 KV	15 (5)						
Over 200 KV to 350 KV	20(6)						
Over 350 KV to 500 KV	25 (8)						
Over 500 KV to 750 KV	35(11)						
Over 750 KV to 1000 KV	45 (14)						
NOTE: This requirement shall apply except where employer, local or governmental regulations are more stringent.							

• Maintain a clearance of at least 10 ft. (3m) between any part of the machine and its occupants, their tools, and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less.


• The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment.

# **DANGER**

DO NOT MANEUVER MACHINE OR PERSONNEL INSIDE PROHIBITED ZONE (MAD). ASSUME ALL ELECTRICAL PARTS AND WIRING ARE ENERGIZED UNLESS KNOWN OTH-ERWISE.

# **Tipping Hazards**

• The user must be familiar with the surface before driving. Do not exceed the allowable sideslope and grade while driving.



- Do not elevate platform or drive with platform elevated while on or near a sloping, uneven, or soft surface. Ensure machine is positioned on a firm, level and smooth surface before elevating platform or driving with the platform in the elevated position.
- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.

- Never exceed the maximum work load as specified on the platform. Keep all loads within the confines of the platform, unless authorized by JLG.
- Keep the chassis of the machine a minimum of 2 ft. (0.6m) from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards at the ground level.
- Do not push or pull any object with the boom.
- Never attempt to use the machine as a crane. Do not tie-off machine to any adjacent structure. Never attach wire, cable, or any similar items to platform.
- If boom assembly or platform is in a position that one or more wheels are off the ground, all persons must be removed before attempting to stabilize the machine. Use cranes, forklift trucks, or other appropriate equipment to stabilize machine.

- Do not operate the machine when wind conditions, including gusts, may exceed 28 mph (12.5 m/s). Factors affecting wind speed are; platform elevation, surrounding structures, local weather events, and approaching storms. Refer to Table 1-2, Beaufort scale (For Reference Only) or use other means to monitor wind conditions.
- Wind speed can be significantly greater at height than at ground level.
- Wind speed can change rapidly. Always consider approaching weather events, the time required to lower the platform, and methods to monitor current and potential wind conditions.
- Do not increase surface area of the platform or the load. Increased areas exposed to wind will decrease stability.
- Do not increase the platform size with unauthorized modifications or attachments.

# NOTICE

#### DO NOT OPERATE THE MACHINE WHEN WIND CONDITIONS EXCEED 28 MPH (12.5 M/

S).

Beaufort	Wind Speed		Description	Land Conditions		
Number	mph	m/s				
0	0	0-0.2	Calm	Calm. Smoke rises vertically		
1	1-3	0.3-1.5	Lightair	Wind motion visible in smoke		
2	4-7	1.6-3.3	Light breeze	Wind felt on exposed skin. Leaves rustle		
3	8-12	3.4-5.4	Gentle breeze	Leaves and smaller twigs in constant motion		
4	13-18	5.5-7.9	Moderate breeze	Dust and loose paper raised. Small branches begin to move.		
5	19-24	8.0-10.7	Fresh breeze	Smaller trees sway.		
6	25-31	10.8-13.8	Strong breeze	Large branches in motion. Flags waving near horizontal. Umbrella use becomes difficult.		
7	32-38	13.9-17.1	Near Gale/Moderate Gale	Whole trees in motion. Effort needed to walk against the wind.		
8	39-46	17.2-20.7	Fresh Gale	Twigs broken from trees. Cars veer on road.		
9	47-54	20.8-24.4	Strong Gale	Light structure damage.		

#### Table 1-2. Beaufort Scale (For Reference Only)

#### **SECTION 1 - SAFETY PRECAUTIONS**

# **Crushing and Collision Hazards**

- Approved head gear must be worn by all operating and ground personnel.
- Check work area for clearances overhead, on sides, and bottom of platform when lifting or lowering platform, and driving.



- During operation, keep all body parts inside platform railing.
- Use the boom functions, not the drive function, to position the platform close to obstacles.
- Always post a lookout when driving in areas where vision is obstructed.

- Keep non-operating personnel at least 6 ft. (1.8m) away from machine during all driving and swing operations.
- Under all travel conditions, the operator must limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors which may cause collision or injury to personnel.
- Be aware of stopping distances in all drive speeds. When driving in high speed, switch to low speed before stopping. Travel grades in low speed only.
- Do not use high speed drive in restricted or close quarters or when driving in reverse.
- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Be sure that operators of other overhead and floor level machines are aware of the aerial work platform's presence. Disconnect power to overhead cranes.
- Warn personnel not to work, stand, or walk under a raised boom or platform. Position barricades on floor if necessary.

# 1.4 TOWING, LIFTING, AND HAULING

- Never allow personnel in platform while towing, lifting, or hauling.
- This machine should not be towed, except in the event of emergency, malfunction, power failure, or loading/unloading. Refer to the Emergency Procedures section of this manual for emergency towing procedures.
- Ensure boom is in the stowed position and, if equipped, the turntable locked prior to towing, lifting or hauling. The platform must be completely empty of tools.
- When lifting machine, lift only at designated areas of the machine. Lift the unit with equipment of adequate capacity.
- Refer to the Machine Operation section of this manual for lifting information.

# **1.5 MAINTENANCE**

This sub-section contains general safety precautions which must be observed during maintenance of this machine. Additional precautions to be observed during machine maintenance are inserted at the appropriate points in this manual and in the Service and Maintenance Manual. It is of utmost importance that maintenance personnel pay strict attention to these precautions to avoid possible injury to personnel or damage to the machine or property. A maintenance program must be established by a qualified person and must be followed to ensure that the machine is safe.

# **Maintenance Hazards**

- Shut off power to all controls and ensure that all moving parts are secured from inadvertent motion prior to performing any adjustments or repairs.
- Never work under an elevated platform until it has been fully lowered to the full down position, if possible, or otherwise supported and restrained from movement with appropriate safety props, blocking, or overhead supports.
- DO NOT attempt to repair or tighten any hydraulic hoses or fittings while the machine is powered on or when the hydraulic system is under pressure.
- Always relieve hydraulic pressure from all hydraulic circuits before loosening or removing hydraulic components.

• DO NOT use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



- Do not use machine as a ground for welding.
- When performing welding or metal cutting operations, precautions must be taken to protect the chassis from direct exposure to weld and metal cutting spatter.
- Do not refuel the machine with the engine running.
- Use only approved non-flammable cleaning solvents.
- Do not replace items critical to stability, such as batteries or solid tires, with items of different weight or specification. Do not modify unit in any way to affect stability.
- Refer to the Service and Maintenance Manual for the weights of critical stability items.

# 

- Ensure replacement parts or components are identical or equivalent to original parts or components.
- Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. Ensure adequate support is provided when raising components of the machine.

# MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.

### **Battery Hazards**

- Always disconnect batteries when servicing electrical components or when performing welding on the machine.
- Do not allow smoking, open flame, or sparks near battery during charging or servicing.
- Do not contact tools or other metal objects across the battery terminals.
- Always wear hand, eye, and face protection when servicing batteries. Ensure that battery acid does not come in contact with skin or clothing.

# 

# BATTERY FLUID IS HIGHLY CORROSIVE. AVOID CONTACT WITH SKIN AND CLOTHING AT ALL TIMES. IMMEDIATELY RINSE ANY CONTACTED AREA WITH CLEAN WATER AND SEEK MEDICAL ATTENTION.

- Charge batteries only in a well ventilated area.
- Avoid overfilling the battery fluid level. Add distilled water to batteries only after the batteries are fully charged.

#### **SECTION 1 - SAFETY PRECAUTIONS**

NOTES:	

# SECTION 2. USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

# 2.1 PERSONNEL TRAINING

The aerial platform is a personnel handling device; so it is necessary that it be operated and maintained only by trained personnel.

Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

# **Operator Training**

Operator training must cover:

- 1. Use and limitations of the controls in the platform and at the ground, emergency controls and safety systems.
- 2. Control labels, instructions, and warnings on the machine.
- 3. Rules of the employer and government regulations.
- 4. Use of approved fall protection device.
- **5.** Enough knowledge of the mechanical operation of the machine to recognize a malfunction or potential malfunction.

- **6.** The safest means to operate the machine where overhead obstructions, other moving equipment, and obstacles, depressions, holes, or drop-offs exist.
- **7.** Means to avoid the hazards of unprotected electrical conductors.
- 8. Specific job requirements or machine application.

# **Training Supervision**

Training must be done under the supervision of a qualified person in an open area free of obstructions until the trainee has developed the ability to safely control and operate the machine.

# **Operator Responsibility**

The operator must be instructed that he/she has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site.

# 2.2 PREPARATION, INSPECTION, AND MAINTENANCE

The following table covers the periodic machine inspections and maintenance required by JLG Industries, Inc. Consult local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as necessary when the machine is used in a harsh or hostile environment, if the machine is used with increased frequency, or if the machine is used in a severe manner.

# NOTICE

JLG INDUSTRIES, INC. RECOGNIZES A FACTORY TRAINED SERVICE TECHNICIAN AS A PERSON WHO HAS SUCCESSFULLY COMPLETED THE JLG SERVICE TRAINING SCHOOL FOR THE SPECIFIC JLG PRODUCT MODEL.


Туре	Frequency	Primary Responsibility	Service Qualification	Reference				
Pre-Start Inspection	Before using each day; or whenever there's an Operator change.	User or Operator	User or Operator	Operator and Safety Manual				
Pre-Delivery Inspection (See Note)	Before each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form				
Frequent Inspection (See Note)	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or Purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form				
Annual Machine Inspection (See Note)	Annually, no later than 13 months from the date of prior inspection.	Owner, Dealer, or User	Factory Trained Service Technician (Recommended)	Service and Maintenance Manual and applicable JLG inspection form				
Preventative Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual				
<b>NOTE:</b> Inspection forms are available from JLG. Use the Service and Maintenance Manual to perform inspections.								

#### Table 2-1. Inspection and Maintenance Table

# **Pre-Start Inspection**

The Pre-Start Inspection should include each of the following:

- 1. **Cleanliness** Check all surfaces for leakage (oil, fuel, or battery fluid) or foreign objects. Report any leakage to the proper maintenance personnel.
- **2. Structure** Inspect the machine structure for dents, damage, weld or parent metal cracks or other discrepancies.



**3.** Decals and Placards – Check all for cleanliness and legibility. Make sure none of the decals and placards are missing. Make sure all illegible decals and placards are cleaned or replaced.

- 4. Operation and Safety Manuals Make sure a copy of the Operation and Safety Manual, AEM Safety Manual (ANSI markets only), and ANSI Manual of Responsibilities (ANSI markets only) is enclosed in the weather resistant storage container.
- **5. "Walk-Around" Inspection** Refer to Figure 2-2., Figure 2-3., and Figure 2-4.
- 6. Battery Charge as required.
- **7. Fuel** (Generator Equipped Machines) Add the proper fuel as necessary.
- 8. Engine Oil Supply (Generator Equipped Machines) Ensure the engine oil level is at the Full mark on the dipstick and the filler cap is secure.
- **9.** Hydraulic Oil Check the hydraulic oil level. Ensure hydraulic oil is added as required.
- **10. Accessories/Attachments** Reference the Operator and Safety Manual of each attachment or accessory installed upon the machine for specific inspection, operation, and maintenance instructions.

**11. Function Check** – Once the "Walk-Around" Inspection is complete, perform a functional check of all systems in an area free of overhead and ground level obstructions. Refer to Section 4 for more specific operating instructions.

# A WARNING

IF THE MACHINE DOES NOT OPERATE PROPERLY, TURN OFF THE MACHINE IMMEDI-ATELY! REPORT THE PROBLEM TO THE PROPER MAINTENANCE PERSONNEL. DO NOT OPERATE THE MACHINE UNTIL IT IS DECLARED SAFE FOR OPERATION.

# **Function Check**

A functional check of all systems should be performed, once the walk-around inspection is complete, in an area free of overhead and ground level obstructions. First, using the ground controls, check all functions controlled by the ground controls. Next, using the platform controls, check all functions controlled by the platform controls.

# **WARNING**

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVERS OR TOGGLE SWITCHES CONTROLLING PLATFORM MOVEMENTS DO NOT RETURN TO THE OFF POSITION WHEN RELEASED.

# 

TO AVOID A COLLISION AND INJURY IF PLATFORM DOES NOT STOP WHEN A CONTROL SWITCH OR LEVER IS RELEASED, REMOVE FOOT FROM FOOTSWITCH OR USE EMER-GENCY STOP TO STOP MACHINE.

- **1.** Check boom limit switches. Raise and lower the Lower Boom. Check for smooth operation.
- **NOTE:** Perform checks from ground controls first, then from platform controls.
  - **2.** Raise, extend, retract, and lower the Upper Boom. Check for smooth operation.
  - **3.** If tower boom does not rest on stop with machine in the stowed position, this indicates upright is out of plumb.
  - **4.** Telescope boom In and Out several cycles at various degrees of elevation lengths. Check for smooth telescope operation.
  - **5.** Swing turntable to Left and Right a minimum of 45 degrees. Check for smooth motion.
  - 6. Check the chassis tilt indicator located on the platform control console by driving, with the machine in stowed position, up a suitable ramp of at least 6° slope. Check the tilt alarm, with the machine on the ramp, raise the upper boom until it is parallel with the chassis. DO NOT RAISE ABOVE THE PARAL-LEL POSITION. If the light does not illuminate, return the

#### SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

machine to a level surface, shut down the machine, and contact a qualified technician before resuming operation.

For units equipped with optional tilt cutout, verify that the drive function is cutout when the boom is elevated and tilt alarm is activated.

# A WARNING

# DO NOT DRIVE ON GRADES WHICH EXCEED THE RATED GRADEABILITY OF THE MACHINE AS INDICATED ON THE SERIAL NUMBER PLATE. DO NOT DRIVE ON SIDES-LOPES WHICH EXCEED 5 DEGREES.

- **7.** Check that platform self-leveling system functions properly during raising and lowering of boom.
- **8.** Check rotator for smooth operation and assure platform will rotate 75 degrees in both directions from centerline of boom.
- 9. Drive forward and reverse; check for proper operation.
- **10.** Steer left and right; check for proper operation.
- 11. Footswitch.

# **WARNING**

FOOTSWITCH MUST BE ADJUSTED SO THAT FUNCTIONS WILL OPERATE WHEN PEDAL IS APPROXIMATELY AT ITS CENTER OF TRAVEL. IF SWITCH OPERATES WITHIN LAST 1/ 4" (6 MM) OF TRAVEL, TOP OR BOTTOM, IT SHOULD BE ADJUSTED.



# FOOTSWITCH MUST BE DEPRESSED PRIOR TO ACTIVATING ANY FUNCTION CONTROL, OTHERWISE THE FUNCTION WILL NOT WORK.


With footswitch depressed, operate LIFT and hold control. Remove foot from footswitch, motion should stop. If it does not, shut down machine and contact a qualified service technician.

- **12.** Place the Ground/Platform Select switch to Ground. Platform controls should not operate.
- **13.** Place Ground/Platform Select switch to Off. Platform/ Ground controls should not operate.

# **SkyGuard Function Test**

From the Platform Console:

Test the SkyGuard feature by operating the telescope out functions and then activating the SkyGuard sensor. The telescope out function will stop and the telescope in function will operate for a short duration and the horn will sound until the SkyGuard sensor and footswitch are disengaged.




**NOTE:** If equipped, ensure the blue beacon illuminates when SkyGuard is activated.

Disengage the SkyGuard sensor, release controls, recycle the foot switch, make sure normal operation is available.

If SkyGuard remains activated after function reversal or cutout, depress and hold the SkyGuard Override Switch to allow normal use of machine functions until the SkyGuard sensor is disengaged.

#### SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION






Figure 2-2. Daily Walk-Around Inspection - Sheet 1 of 3

#### General

Begin the "Walk-Around Inspection" at Item 1, as noted on the diagram. Continue to the right (counterclockwise viewed from top) checking each item in sequence for the conditions listed in the "Walk-Around Inspection Checklist".

# **WARNING**

TO AVOID POSSIBLE INJURY BE SURE MACHINE POWER IS OFF DURING "WALK-AROUND INSPECTION".

# NOTICE

# DO NOT OVERLOOK VISUAL INSPECTION OF CHASSIS UNDERSIDE. CHECKING THIS AREA MAY RESULT IN DISCOVERY OF CONDITIONS WHICH COULD CAUSE EXTENSIVE MACHINE DAMAGE.

**NOTE:** On each item, make sure there are no loose or missing parts, that they are securely fastened and that no visible damage exists in addition to any other criteria mentioned.

- 1. Platform and Gate Assembly Platform mounting pins secure. Footswitch in good working order; not modified, disabled or blocked; Bar slides freely.
- **2.** Platform & Ground Control Console Switches and levers return to neutral and are properly secured, decals/placards secure and legible, control marking legible.
- 3. Rotator See Note.
- 4. Jib See Note.
- 5. Jib Rotator See Note.
- 6. Boom Sections See Note.
- 7. All Hydraulic Cylinders No visible damage; pivot pins and hydraulic hoses undamaged, not leaking.
- 8. Limit Switches See Note.

Figure 2-3. Daily Walk-Around Inspection - Sheet 2 of 3

- **9.** Drive Axle and Motor See Note.
- Wheel/Tire Assembly No loose or missing lug nuts. Inspect for worn tread, cuts, tears or other discrepancies. Inspect wheels for damage and corrosion.
- 11. Swing Motor and Worm Gear See Note.
- **12.** Hydraulic Pump and Reservoir Properly secured; no visible damage or hydraulic leaks. Recommended hydraulic fluid level on dipstick (system shut down, boom in stowed position). Breather cap/dipstick secure and working.
- **13.** Turntable Bearing No loose or missing hardware; no visible damage; evidence of proper lubrication. No loose bolts or looseness between bearing and structure.
- **14.** Battery Compartment Right Side Batteries have proper electrolyte level; cables tight; no visible damage or corrosion.
- **15.** Cowling and Latches See Note.

- **16.** Battery Charger See Note.
- 17. Brake/Steer Valve See Note.
- Boom/Upright No visible damage; All pins properly secured. Upright in vertical position. If Upright does not rest on stop with machine in the stowed position, this indicates upright is out of plumb.
- **19.** Counterweight See Note.
- **20.** Tie Rod Ends and Steering Spindles See Note. Tie rod end stubs locked.
- 21. Manual Descent Valve See Note.
- **22.** Control Valve See Note.
- 23. Frame See Note.
- 24. Platform Pivot Pins Properly secured.
- 25. SkyGuard (If Equipped) See Inspection Note.

#### Figure 2-4. Daily Walk-Around Inspection - Sheet 3 of 3

#### SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

NOTES:	
	·
	· · · · · · · · · · · · · · · · · · ·

# SECTION 3. MACHINE CONTROLS AND INDICATORS

#### 3.1 GENERAL



THE MANUFACTURER HAS NO DIRECT CONTROL OVER MACHINE APPLICATION AND OPERATION. THE USER AND OPERATOR ARE RESPONSIBLE FOR CONFORMING WITH GOOD SAFETY PRACTICES.

This section provides the necessary information needed to understand control functions.

#### 3.2 CONTROLS AND INDICATORS

**NOTE:** All machines are equipped with control consoles that use symbols to indicate control functions. On ANSI machines refer to decal located on the control box guard in front of the control box or by the ground controls for these symbols and the corresponding functions.

**NOTE:** The indicator panels use different shaped symbols to alert the operator to different types of operational situations that could arise. The meaning of those symbols are explained below.



Indicates a potentially hazardous situation, which if not corrected, could result in serious injury or death. This indicator will be red.



Indicates an abnormal operating condition, which if not corrected, may result in machine interruption or damage. This indicator will be yellow.



Indicates important information regarding the operating condition, i.e. procedures essential for safe operation. This indicator will be green with the exception of the capacity indicator which will be green or yellow depending upon platform position.

#### **Ground Control Console**

# 

# TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVERS OR TOGGLE SWITCHES CONTROLLING PLATFORM MOVEMENT DO NOT RETURN TO THE OFF POSITION WHEN RELEASED.

#### (See Figure 3-1.)

- **NOTE:** When machine is shut down the Platform/Ground Select switch and Emergency Stop must be positioned to Off.
- **NOTE:** The Function Enable switch must be held down in order to operate Telescope, Lower Lift, Swing, Main Lift, Jib Lift, Platform Level Override, and Platform Rotate functions.
  - 1. System Distress Indicator (If Equipped)

trical system fault.

The system distress indicator lights to sig-

nify an abnormal condition for the genera-

tor engine (high oil temperature or low oil

pressure) or, on electric machines, an elec-

**NOTE:** The engine will automatically shut down under the following conditions:

High Oil Temperature Low Oil Pressure Engine Overspeed Overvoltage

2. Platform Overload (If equipped)


Indicates the platform has been overloaded.



3. Generator/Engine Start Button (If equipped)

The generator/engine start push-button switch allows the generator to be started manually to top-off the battery charge. The generator will start automatically when the batteries reach a low-charge state and the Generator Enable switch on the platform console is in the on position.

**NOTE:** The engine will not start if the batteries are fully charged or if the Generator Enable switch on the platform console is not in the on position.



- 1. System Distress Indicator
- 2. Platform Overload Indicator (If Equipped)
- 3. Generator/Engine Start Button
- 4. Indicator Gauge
- 5. Charger Status
- 6. Telescope
- 7. Machine Safety System Override (MSSO) (If Equipped)
- 8. Swing
- 9. Function Enable
- 10. Circuit Breakers
- 11. Power/Emergency Stop
- 12. Platform/Ground Select
- 13. Lower/Mid Lift
- 14. Upper Boom Lift
- 15. Jib
- 16. Platform Leveling
- 17. Rotate

Figure 3-1. Ground Control Console

#### 4. Indicator Gauge

Registers the amount of time the machine has been in use, with functions operating. In the event of a fault, the hourmeter also displays the three digit fault code. Refer to the



Service Manual for a listing of fault codes. Additionally, there is a small, red indicator light that will blink when there is a fault on the machine to draw operator attention to the display.

5. Charger Status

The Charger Status LEDs give a visual indicator of the status of the battery charger. The red LED indicates Charging Abnormal. The yellow LED indicates charging in progress. The green LED indicates charging is complete.

#### 6. Telescope

Provides for extension and retraction of Upper Boom when positioned to in or out.



 Machine Safety System Override (MSSO) (CE Only)

Load Sense System activation.

Provides emergency override of function

controls that are locked out in the event of



8. Swing

The Swing control switch provides 360 degrees non-continuous turntable rotation. To activate SWING, position switch to Left or Right.



9. Function Enable

The enable switch must be held "Down" to enable all boom controls when the engine is running.



#### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

#### 10. Circuit Breakers

The circuit breakers open (pop out) to indicate a short or overload somewhere on the machine.

**11.** Power/Emergency Stop Switch

A two-position red mushroom shaped switch furnishes power to Platform/Ground Select switch when pulled out (on). When pushed in

(off), power is shut off to the Platform/Ground Select switch.

12. Platform/Ground Select Switch

A three position, key operated switch supplies power to the platform control console when positioned to Platform. With the switch key in the Ground position, power is shut off to platform and only ground controls are operable.

**NOTE:** With Platform/Ground Select switch in the center position, power is shut off to controls at both operating stations.

#### 13. Lower/Mid Boom Lift


Provides for raising and lowering of Lower Boom when positioned to Up or Down.



14. Upper Boom Lift

Provides for raising and lowering of Upper Boom when positioned to Up or Down.





#### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

#### 15. Jib (If equipped)

The Jib control switch provides raising and lowering of the jib when positioned up or down.



#### A WARNING

#### ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANT TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

16. Platform Leveling Override

A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust platform level in situations such as ascending/descending a grade.

#### 17. Rotate

A three position Rotate control switch permits rotation of the platform when positioned to left or right.



#### **Platform Control Console**

(See Figure 3-2.)

1. Speed Mode

Activating the Speed Mode switch allows the operator to High or Low Speed travel operation.








#### ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANT TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

2. Platform Leveling Override

A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust platform level in situations such as ascending/descending a grade.





- 1. Speed Mode
- 2. Platform Leveling Override
- 3. Horn
- 4. Power/Emergency Stop
- 5. Generator Enable
- 6. Drive Orientation Override 10
- 7. Drive/Steer
- 8. Telescope

- 9. Lights e 10. Jib
  - Jib
    Soft Touch/SkyGuard Override (If Equipped)

12. Lower Boom Lift

- 13. Platform Rotate
  - 14. Function Speed
  - 15. Main Lift/Swing

Figure 3-2. Platform Console

#### 3. Horn

A push-type Horn switch supplies electrical power to an audible warning device when pressed.

4. Power/Emergency Stop



Lo

A two-position red mushroom shaped switch furnishes power to Platform Controls when pulled out (on). When pushed in (off), power is shut off to the platform functions.

Within about 2 seconds of pulling the switch out, the machine will perform a diagnostic check of the various electrical circuits, and if everything is OK, the platform alarm will beep once. During this time the lights on the indicator panel will also blink once as a bulb check.

5. Generator Enable Control (If equipped)

The Generator Enable control switch, when in the off position, allows the operator to prevent the generator engine from starting when using the machine indoors. When in the on position (and the ground Emergency Stop Switch on [pulled out]), the generator is enabled to automatically start when the batteries need charged. 6. Drive Orientation Override

When the boom is swung over the rear tires or further in either direction, the Drive Orientation indicator will illuminate when the drive function is selected. Push and release the



switch, and within 3 seconds move the Drive/Steer control to activate drive or steer. Before driving, locate the black/ white orientation arrows on both the chassis and the platform controls and match the control direction arrow to the intended direction of travel.

- **NOTE:** To operate the Drive joystick, pull up on the locking ring below the handle.
- **NOTE:** The Drive joystick is spring loaded and will automatically return to neutral (off) position when released.
  - 7. Drive/Steer

The Drive controller provides for driving either forward or backward when positioned to Forward or Reverse. The controller is 'ramped' to allow infinitely variable drive speed between fast and slow.

Positioning the steer control thumb operated switch Right or Left enables steering the machine to the right or left respectively.

**NOTE:** When lower boom is raised above horizontal, or the upper boom is raised approximately 16 inches (40.64 cm) above boom rest, the high drive function will automatically switch to low drive. This also occurs when Function Speed Control is clicked on creep.

# 

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVERS OR TOGGLE SWITCHES CONTROLLING PLATFORM MOVEMENT DO NOT RETURN TO THE OFF OR NEUTRAL POSITION WHEN RELEASED.

8. Telescope Control

The Telescope control switch affords extension and retraction of the main boom when positioned to In or Out.

**9.** Lights (If Equipped)

This switch operates control console panel lights and head lights if the machine is so equipped.


**10.** Jib (If Equipped)

Push forward to lift up, pull back to lift down. Variable lift speed is using the Function Speed Control.



3-9





3-10

**11.** Soft Touch/SkyGuard Override Switch (If equipped)


The machine can be equipped with one of three options. It may have Soft Touch, SkyGuard, or both Soft Touch and Sky-Guard.

If equipped with Soft Touch, the switch enables the functions that were cut out by the Soft Touch system to operate again at creep speed, allowing the

operator to move the platform away from the obstacle that caused the shutdown situation.

If equipped with SkyGuard, the switch enables functions cut out by the Skyguard system to be operated again, allowing the operator to resume use of machine functions.

If equipped with both Soft Touch and SkyGuard, the switch operates like described above and allows the operator to override the system that has experienced a cutout situation.



Provides for raising and lowering of Lower and Mid Boom when positioned to Up or Down. Upper lift will not function when operating lower lift.

13. Platform Rotate

The Platform Rotate control switch allows the operator to rotate the basket to the left or right when positioned to the desired direction.





#### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

14. Function Speed Control

Adjusts speed of Boom and Swing Functions. Rotate counterclockwise for slower speed and clockwise for faster speed. To adjust Drive, Swing, and Main Lift to creep, turn knob fully counterclockwise until it clicks.



**NOTE:** To operate the Main Boom Lift/Swing joystick, pull up on the locking ring below the handle.



- **NOTE:** The Main Boom Lift/Swing joystick is spring loaded and will automatically return to neutral (off) position when released.
  - 15. Main Lift/Swing Controller

Provides main lift and swing. Push forward to lift up, pull backward to boom down. Move right to swing right, move left to swing left. Moving the joystick activates switches to provide the functions selected.



**NOTE:** Lower lift will not function when operating main lift.

If This Function is Selected:	These Functions Will Also Work at the Same Time:						
Drive and Steer		Swing	Lower Lift**	Upper Lift**	Telescope		
Swing	Drive and Steer		Lower Lift**	Upper Lift**	Telescope		
LowerLift	Drive and Steer	Swing*		No	Telescope*		
Upper Lift	Drive and Steer	Swing	No		Telescope		
Telescope	Drive and Steer	Swing*	Lower Lift**	Upper Lift**			
Jib	Drive and Steer	Swing*	Lower Lift**	Upper Lift**	Telescope		
Platform Rotate	Drive and Steer	No	No	No	No		

#### Table 3-1. Simultaneous Functions

Note: Boom functions may be slower when selected with another function than when operated individually, due to sharing of oil.

\* These functions may move very slowly (or not at all) if the first function selected (Lower Lift or Swing) is being operated at full speed, due to sharing of oil.

\*\* Lower Lift and Upper Lift will not function simultaneously. Upper Lift always prevails.

#### **Platform Control Indicator Panel**

(See Figure 3-3., Platform Control Indicator Panel)

1. Tilt Alarm Warning Light and Alarm

This illuminator indicates that the chassis is on a slope. An alarm will also sound when the chassis is on a slope and the boom is above horizontal. If lit when boom is raised or

I

extended, retract and lower to below horizontal then reposition machine so that it is level before continuing operation. If the boom is above horizontal and the machine is on a slope, the tilt alarm warning light will illuminate and an alarm will sound and Creep is automatically activated.


# **WARNING**

IF TILT WARNING LIGHT IS ILLUMINATED WHEN BOOM IS RAISED OR EXTENDED, RETRACT AND LOWER TO BELOW HORIZONTAL THEN REPOSITION MACHINE SO THAT IT IS LEVEL BEFORE EXTENDING BOOM OR RAISING BOOM ABOVE HORIZONTAL. 2. Platform Overload (If equipped)

Indicates the platform has been overloaded.



#### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**



4. Drive Orientation

Figure 3-3. Platform Control Indicator Panel

3. System Distress Indicator

system fault.

The system distress indicator lights to signify an abnormal condition for the generator engine (high oil temperature or low oil pressure) or, on all electric machines, an electrical

The four likely causes of a system fault are:

- a. The seven second enable time has been allowed to lapse or a function was selected before depressing the footswitch. The system reads this condition as a fault, just as it would if the footswitch were jammed in the depressed position or a function switch were stuck in the on position. Re-depress the footswitch to power the controls and extinguish the light.
- **b.** The maximum power limit has been reached and the machine is not moving. This could happen when the machine is stuck or when attempting to travel over rough terrain or on steep grades which exceed the rated gradeability of the machine. This condition is comparable to stalling the engine by asking it to provide more power than it was designed to do.
- **c.** The batteries are nearly depleted, and should be charged very soon to prevent having the machine stop at an inconvenient place.

- **d.** There is some other fault in one of the circuits. If so determine the cause by counting the flash code, a number of flashes followed by a pause followed by another number of flashes, and refer to the service manual.
- **NOTE:** The engine will automatically shut down under the following conditions:

High Engine Oil Temperature Low Engine Oil Pressure Engine Overspeed Generator Overvoltage

4. Drive Orientation Indicator

When the boom is swung beyond the rear drive tires or further in either direction, the Drive Orientation indicator will illuminate when the drive function is selected. This is a



signal for the operator to verify that the drive control is being operated in the proper direction (i.e. controls reversed situations).

#### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

5. Enable Indicator/Footswitch

To operate any function, the footswitch must be depressed and the function selected within seven seconds. The enable indicator shows that the controls are



enabled. If a function is not selected within seven seconds, or if a seven second lapse between ending one function and beginning the next function, the enable light will go out and the footswitch must be released and depressed again to enable the controls.

Releasing the footswitch removes power from all controls and applies the drive brakes.

# 


TO AVOID SERIOUS INJURY, DO NOT REMOVE, MODIFY OR DISABLE THE FOOTSWITCH BY BLOCKING OR ANY OTHER MEANS.

# 

FOOTSWITCH MUST BE ADJUSTED IF FUNCTIONS ACTIVATE WHEN SWITCH ONLY OPERATES WITHIN LAST 1/4" OF TRAVEL, TOP OR BOTTOM.

6. Battery Charge Indicator

This indicator lights to show the state-ofcharge of the battery pack..



7. Low Battery Indicator

Indicates the batteries are low and need to be charged.



8. SkyGuard (If Equipped)

When illuminated indicates the SkyGuard sensor has been activated. All controls are cut out until the override button is pushed, at which time controls will work normally.



9. Soft Touch Indicator (If Equipped)

When illuminated (Yellow) the Soft Touch bumper is against an object. All controls are disabled until the override button is pushed, at which time controls are active in the Creep mode.



#### 10. Creep Speed Indicator

When the Function Speed Control is turned to the creep position, the indicator acts as a reminder that all functions are set to the slowest speed.



NOTES:	

# **SECTION 4. MACHINE OPERATION**

#### 4.1 **DESCRIPTION**

This machine is a self-propelled hydraulic personnel lift equipped with a work platform on the end of an elevating and rotating boom.

The primary operator control station is in the platform. From this control station, the operator can drive and steer the machine in both forward and reverse directions. The operator can raise or lower the upper or lower boom or swing the boom to the left or right. Standard boom swing is 360 degree non-continuous left and right of the stowed position. The machine has a Ground Control Station which will override the Platform Control Station. Ground Controls operate Upper and Lower Boom Lift and Swing, and are to be used in an emergency to lower the platform to the ground should the operator in the platform be unable to do so.

# 4.2 BOOM OPERATING CHARACTERISTICS AND LIMITATIONS

#### Capacities

The boom can be raised above horizontal with or without any load in platform, if:

- 1. Machine is positioned on a smooth, firm and level surface.
- 2. Load is within manufacturers rated design capacity.
- 3. All machine systems are functioning properly.
- 4. Proper tire pressure.
- 5. Machine is as originally equipped from JLG.

# Stability

Machine stability is based on two positions which are called Forward and Backward stability. The machines position of least Forward stability is shown in Figure 4-1., Position of Least Forward Stability, and its position of least Backward stability is shown in Figure 4-2., Position of Least Backward Stability.

# **WARNING**

TO AVOID FORWARD OR BACKWARD TIPPING, DO NOT OVERLOAD MACHINE OR OPER-ATE THE MACHINE ON AN OUT-OF-LEVEL SURFACE.

# 4.3 MOTOR OPERATION

#### **Power/Emergency Stop**

The Power/Emergency Stop switch, when pulled out (on), provides battery power for all machine functions. The switch should be pushed in (off) when recharging the batteries or parking the machine overnight.



**NOTE:** If equipped with the optional on-board generator, the Emergency Stop switch must be left on (pulled out) to allow for automatic charging of the batteries.

Within about 2 seconds of pulling the switch out, the machine will perform a diagnostic check of the various electrical circuits, and if everything is OK, the platform alarm will beep once. During this time the lights on the indicator panel will also blink once as a bulb check.





Figure 4-1. Position of Least Forward Stability

#### **SECTION 4 - MACHINE OPERATION**



#### **Platform/Ground Select Switch**

The Platform/Ground Select switch directs battery power to the desired control station when the Power/Emergency Stop switch is pulled out (on). With the switch held in the Ground position battery power is supplied to the ground control station. When the switch is in the Platform position, battery power is supplied to the platform control station.

# 4.4 TRAVELING (DRIVING)

- **NOTE:** For units equipped with optional tilt cutout, verify that the drive function is cut out when the boom is elevated and tilt alarm is activated.
- **NOTE:** When lower boom is raised above horizontal, or the upper boom is raised approximately 16 inches (40.6 cm) above boom rest, the high drive function will automatically be in low drive.

# NOTICE

IF THE MACHINE IS OPERATED AT A VERY SLOW SPEED OR STALLED WHEN CLIMBING A GRADE OF 20% OR GREATER, DRIVE FUNCTION WILL STOP. REMOVE FOOT FROM FOOT-SWITCH, AND DEPRESS FOOTSWITCH TO RESET.

# 

DO NOT DRIVE WITH BOOM ABOVE HORIZONTAL EXCEPT ON A SMOOTH, FIRM AND LEVEL SURFACE.

TO AVOID LOSS OF TRAVEL CONTROL OR "TIP OVER" ON GRADES AND SIDE SLOPES, DO NOT DRIVE MACHINE ON GRADES EXCEEDING THOSE SPECIFIED ON THE SERIAL NUMBER PLATE.

DO NOT DRIVE ON SIDESLOPES WHICH EXCEED 5 DEGREES. AVOID ANY TERRAIN FEATURES WHICH COULD CAUSE THE MACHINE TO TIP OVER.

#### **Motor Activation**

#### NOTICE

#### FOOTSWITCH MUST BE DEPRESSED PRIOR TO ACTIVATING ANY FUNCTION, OTHER-WISE FUNCTION WILL NOT OPERATE.

The motor becomes activated and operates the desired function when the Emergency Stop switch is pulled out (on), the Platform/ Ground select switch is in the appropriate position and the Foot-switch is depressed.

# **A** CAUTION

IF A MOTOR MALFUNCTION NECESSITATES UNSCHEDULED SHUTDOWN, DETERMINE AND CORRECT CAUSE BEFORE RESUMING ANY OPERATION.

USE EXTREME CAUTION WHEN DRIVING IN REVERSE AND AT ALL TIMES WHEN DRIV-ING WITH PLATFORM ELEVATED AND WHEN DRIVING WITH ANY PART OF MACHINE WITHIN 6 FEET OF ANY OBSTRUCTION.

# **WARNING**

BEFORE DRIVING, LOCATE THE BLACK/WHITE ORIENTATION ARROWS ON BOTH THE CHASSIS AND THE PLATFORM CONTROLS. MOVE THE DRIVE CONTROLS IN A DIREC-TION MATCHING THE DIRECTIONAL ARROWS FOR THE INTENDED DIRECTION OF TRAVEL.

#### **Traveling Forward and Reverse**



FOOTSWITCH MUST BE DEPRESSED PRIOR TO ACTIVATING ANY FUNCTION, OTHER-WISE FUNCTION WILL NOT OPERATE.

1. At Platform Controls, pull out Emergency Stop switch and activate footswitch.



2. Position Drive controller to Forward or Reverse as desired. Angle of controller will determine travel speed.



This machine is equipped with a Drive Orientation Indicator. The yellow light on the platform control console indicates that the boom is swung beyond the rear drive tires and the machine may Drive/Steer in the opposite direction from the movement of the controls. If the indicator is illuminated, operate the Drive function in the following manner:





Figure 4-3. Grade and Side Slopes

#### **SECTION 4 - MACHINE OPERATION**

 Match the black and white direction arrows on both platform control panel and the chassis to determine the direction the machine will travel.



2. Push and release the Drive Orientation Override switch. Within 3 seconds, slowly move the Drive control toward the arrow matching the intended direction of machine travel. The indicator light will flash during the 3 second interval until the drive function is selected.



#### Traveling on a Grade

When traveling a grade, maximum braking and traction are obtained with the boom stowed, in position over the rear (drive) axle, and in line with the direction of travel. Drive the machine forward when climbing a grade, and in reverse when descending a grade. Do not exceed the machine's maximum rated gradability.




Figure 4-4. Traveling on a Grade



IF THE BOOM IS OVER THE FRONT (STEER) AXLE, DIRECTION OF STEER AND DRIVE MOVEMENT WILL BE OPPOSITE FROM THE MOVEMENT OF THE CONTROLS.

#### 4.5 STEERING

Depress footswitch, position thumb switch on Drive/Steer controller to Right for steering right, or to Left for steering left.

# 4.6 PLATFORM

#### **Loading From Ground Level**

- 1. Position chassis on a smooth, firm and level surface.
- 2. If total load (personnel, tools and supplies) is 500 LB. (227 kg for ANSI markets and 230 kg for CE and Australia markets) or less, distribute load uniformly on platform floor and proceed to work position.

#### **Loading From Positions Above Ground Level**

Before loading weight to platform above ground level:

- 1. Determine what the total weight will be after additional weight is loaded (personnel, tools and supplies).
- **2.** If total weight in platform will be 500 LBS. (227 kg for ANSI markets and 230 kg for CE and Australia markets) or less, proceed with adding weight.

#### **Platform Level Adjustment**

1. Depress footswitch. To raise platform, position Platform/Level control switch Up and hold until platform is level.



**2.** Depress footswitch. To lower platform, position Platform/Level control switch to Down and hold until platform is level.

# 

ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANT TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

#### **Platform Rotation**

1. Depress footswitch. To rotate platform to the left, Platform Rotate control switch is positioned to the Left and held until desired position is reached.



2. Depress footswitch. To rotate platform to the right, Platform Rotate control switch is positioned to the Right and held until desired position is reached.

# 4.7 BOOM

# 

A RED TILT WARNING LIGHT IS LOCATED ON THE CONTROL CONSOLE WHICH LIGHTS WHEN THE CHASSIS IS ON A 5 DEGREE OR GREATER SLOPE. DO NOT SWING OR RAISE BOOM ABOVE HORIZONTAL WHEN LIGHT IS LIT OR AUDIBLE ALARM SOUNDS.



DO NOT DEPEND ON TILT ALARM AS A LEVEL INDICATOR FOR THE CHASSIS. TILT ALARM INDICATES CHASSIS IS ON A SEVERE SLOPE (5 DEGREE OR GREATER). CHASSIS MUST BE LEVEL BEFORE SWINGING, OR RAISING BOOM ABOVE HORIZONTAL.

TO AVOID TIP OVER IF RED TILT WARNING LIGHT LIGHTS WHEN BOOM IS RAISED ABOVE HORIZONTAL, LOWER PLATFORM TO GROUND LEVEL. THEN REPOSITION MACHINE SO THAT CHASSIS IS LEVEL BEFORE RAISING BOOM.

TRAVELING WITH BOOM BELOW HORIZONTAL IS PERMITTED ON GRADES NOT EXCEEDING THOSE SPECIFIED ON THE SERIAL NUMBER PLATE.

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINERY IF ANY CONTROL LEVER OR TOGGLE SWITCH CONTROLLING PLATFORM MOVEMENT DOES NOT RETURN TO THE 'OFF' OR NEUTRAL POSITION WHEN RELEASED.

TO AVOID A COLLISION AND INJURY IF PLATFORM DOES NOT STOP WHEN A CONTROL SWITCH OR LEVER IS RELEASED, REMOVE FOOT FROM FOOTSWITCH OR USE EMER-GENCY STOP SWITCH TO STOP THE MACHINE.

#### Swinging the Boom

To swing boom, with footswitch activated, position Swing control switch to Right or Left for direction desired.



#### NOTICE

WHEN SWINGING THE BOOM MAKE SURE THERE IS AMPLE ROOM FOR THE BOOM TO CLEAR SURROUNDING WALLS, PARTITIONS AND EQUIPMENT.

## **Raising and Lowering the Lower and Mid Boom**

To raise or lower the Lower and Mid Boom, with footswitch activated, position Lower Boom Lift switch to UP or DOWN as desired.



### **Raising and Lowering the Upper Boom**

To raise or lower the Upper Boom, with footswitch activated, position Upper Boom Lift switch to UP or DOWN until desired height is reached.



#### 4.8 GENERATOR

The machine is equipped with an engine powered DC generator connected in parallel to the 48V DC battery bank.

# **Automatic Operating Mode**

The generator will operate in automatic mode always when the following two conditions apply.

 Ground Control Emergency Stop Switch is pulled out (on), <u>and</u>:



**2.** The Generator Enable switch on the platform control console is in the On or Enable position.



#### **SECTION 4 - MACHINE OPERATION**

When the above conditions apply, the generator's controller will monitor status of the batteries, will turn on automatically when the battery voltage drops as a result of discharge and will turn off when batteries are fully charged.

#### **Battery Only Operating Mode**

The machine will operate in the battery only mode when the following two conditions apply:

 Ground Control Emergency Stop Switch is pulled out (on), <u>and</u>:



**2.** The switch on the platform control console is in the Off or Disable position.

In this mode the machine will operate as a conventional battery operated unit. The batteries can be used until they are fully discharged.

#### Manual (Charge) Operating Mode

The generator will operate in manual mode always when the following three conditions apply.

 Ground Control Emergency Stop Switch is pulled out (on), <u>and</u>:



2. The switch on the platform control console is in the On or Enable position <u>and</u>:



3. The Manual Charge push button is activated.

Activation of the Manual Charge button will start the engine and initiate the charging cycle even if the batteries are charged above the level of automatic start. The operator can initiate the charge cycle to charge the batteries to the maximum level. The charging cycle will include finishing phase similar to conventional chargers.

#### 4.9 INVERTER

The inverter converts 48 VDC to 110 VAC to allow operation of power tools from the machine's batteries.

- The inverter is operational when the emergency stop switch is pulled out.
- The machine and inverter can be operated at the same time.
- The inverter will shut off at approximately 42 VDC and stay off until the emergency stop switch is recycled. It will operate again until voltage drops to 42 VDC.
- The machine will operate down to 36 VDC.
- The inverter will shut down if the high temperature light indicated overheating. It will automatically turn back on when cooled.
- The overload light indicates an output wiring short circuit or a load that is too large for the rating of the inverter.

#### 4.10 MACHINE FUNCTION SPEEDS

The Function Speed Control affects the speed of boom functions Lower Lift, Telescope, and Rotate. Turn the control clockwise to increase function speed or counterclockwise to decrease function speed. When in the counterclockwise maximum position, all functions are placed in creep speed.

# 4.11 MACHINE SAFETY SYSTEM OVERRIDE (MSSO)(CE ONLY)

The Machine Safety System Override (MSSO) is used to override function controls for Emergency Platform Retrieval only. Refer to Section 5.7, Machine Safety System Override (MSSO)(CE Only)for operating procedures.



#### 4.12 SKYGUARD OPERATION

Skyguard is used to provide enhanced control panel protection. When the SkyGuard sensor is activated, functions that were in use at the time of actuation will reverse or cutout. The table below outlines these functions.

Table 4-1. Skyguard Function Table

Main Lift	Main Tele	Swing	Drive Forward		Drive Reverse		Platform Level	Platform Rotate	Jib Lift
R	C/R*	R	R	Ι	R	R	C	C	C
R=Indicates Reversal is Activated									
C=Indicates Cutout is Activated									
= Input is Ignored									
Note: When Soft Touch is enabled with SkyGuard all functions are cut out only.									
* Reversal only applies to Main Tele Out. Main Tele In would be cut out									

#### 4.13 BOOM SYNCHRONIZING PROCEDURE

- **NOTE:** If the Lower Boom assembly does not fully lower:
  - 1. Remove all personnel from the platform.
  - 2. Pull the red knob located beside the main control valve.
  - **3.** From Ground Control, activate the lift control switch, raise Lower Boom 1.8 m (6 feet).
  - 4. After raising Lower Boom, release the red knob.
  - 5. Activate Lower Boom Down, fully lower boom.
  - 6. Repeat step 1 thru 5 if necessary.

## 4.14 SHUT DOWN AND PARK

- **NOTE:** When parking battery powered units overnight, batteries should be charged in accordance with instructions in Section 2 to ensure readiness for following workday.
- **NOTE:** Electric machines are equipped with a static strap due to static electricity build-ups. Strap is located under rear of machine chassis.

To shut down and park the machine, the procedures are as follows:

- 1. Drive machine to a reasonably well protected area.
- 2. Ensure boom is lowered over rear drive axle.
- 3. Shut down Emergency Stop at Platform Controls.
- **4.** Shut down Emergency Stop at Ground Controls. Position Platform/Ground Select switch to center Off.
- **5.** If necessary, cover Platform Controls to protect instruction placards, warning decals and operating controls from hostile environment.

## 4.15 MACHINE LIFTING AND TIE DOWN


See Figure 4-5.

## Lifting

- 1. Refer to the Serial Number Plate, refer to the Specifications section of this manual, or weigh the individual unit to find out the Gross Vehicle Weight.
- **2.** Place the boom in the stowed position.
- 3. Remove all loose items from the machine.
- **4.** Attach lifting device and equipment only to the designated lifting points.
- **5.** Properly adjust the rigging to prevent damage to the machine and so the machine remains level.

### Tie Down

- 1. Place the boom in the stowed position.
- 2. Remove all loose items from the machine.
- **3.** Secure the chassis and the platform using straps or chains of adequate strength.






Figure 4-6. Decal Installation - Sheet 1 of 6




Figure 4-7. Decal Installation - Sheet 2 of 6




Figure 4-8. Decal Installation - Sheet 3 of 6




Figure 4-9. Decal Installation - Sheet 4 of 6




Figure 4-10. Decal Installation - Sheet 5 of 6




Figure 4-11. Decal Installation - Sheet 6 of 6

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
1									
2	1703805		1703938	1703939	1703935	1703936	1703937	1703940	
3									
4	1703798	1705822	1703932	1703933	1703929	1703930	1703931	1703934	1705822
5						1705514			
6	1001131269					1700584			
7	1706948		1706948	1706948	1706948	1706948	1706948	1706948	1001187083
8									
9	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504
10	1701642	1701642	1701642	1701642	1701642	1701642	1701642	1701642	1701642
11	1703797	1705921	1703926	1703927	1703923	1703924	1703925	1703928	1705921
12									
13	1701644	1701644	1701644	1701644	1701644	1701644	1701644	1701644	1701644
14									

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
15		1705828	1703980	1703981	1703983	1703984	1703982	1703985	1705828
16	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277
17								1704008	
18									
19									
20					3251243	3251243		3251243	
21									
22	1701691	1701691	1701691	1701691	1701691	1701691	1701691	1701691	1701691
23	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864
24	1702868				1704001	1704000		1704002	
25	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949
26	1001196811		1001196811		1001196811	1001196811		1001196811	
27	1704446	1706378	1704417	1704418	1704454	1704452	1704419	1704453	1706378
28	1704431	1704431	1704431	1704431	1704431	1704431	1704431	1704431	1704431

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
29									
30									
31									
32									
33									
34									
35									
36									
37	1701500	1703811	1701500	1701500	1701500	1701500	1701500	1701500	1703811
38	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509
39	1703813	1705670	1704342	1704343	1704339	1704340	1704344	1704341	1705670
40	3252347								
41	1703804	1701518	1703950	1703951	1703947	1703948	1703949	1703952	1701518
42									

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
43									
44									
45									
46									
47	1702265	1705977	1702271	1703987	1702265	1702265	1703988	1703991	1705977
48									
49									
50	1702300	1703814	1702300	1702300	1702300	1702300	1702300	1702300	1703814
51									
52	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631
53	1001121814	1705978	1001121821	1001121921	1001121818	1001121816	1001121823	1001121923	1705978
54									
55									
56									

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
57									
58									
59									
60									
61									
62									
63									
64	1706950				1706950	1706950		1706950	
65	1001121801	1705978	1001121808	1001121918	1001121805	1001121803	1001121810	1001121920	1705978
66									
67									
68									
69									
70									

Table 4-2. E450A/E450AJ Decal Legend

ltem #	ANSI 1001178364-D	Aus 1001178378-E	Japanese 1001178372-D	Korean 1001178374-D	Eng/ Lat. Spanish 1001178368-D	Eng/ French 1001178366-D	Chinese /Eng 1001178376-D	Spa/ Portuguese 1001178370-D	CE 1001190003-C
71									
72									
73									
74									
75									
76									
77	1704412	1704412	1704412	1704412	1704412	1704412	1704412	1704412	1704412
78									
79	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885
80									
81	1705351		1705426	1705427	1705910	1705429	1705430	1001113680	
82	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882

Table 4-3. M450AJ Decal Legend

ltem #	ANSI 1001178362-D	Aus 1001178377-E	Japanese 1001178371-D	Korean 1001178373-D	Eng/ Spanish 1001178367-D	Eng/ French 1001178365-D	Chinese 1001178375-D	Spa/ Portuguese 1001178369-D	CE 1001190004-C
1									
2	1703805	1703805	1703938	1703939	1703935	1703936	1703937	1703940	
3									
4	1703798	1705822	1703932	1703933	1703929	1703930	1703931	1703934	1705822
5						1705514			
6	1001131269								
7	1706948	1001126871	1706948	1706948	1706948	1706948	1706948	1706948	1001187083
8									
9	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504
10	1701642	1701642	1701642	1701642	1701642	1701642	1701642	1701642	1701642
11	1703797	1705921	1703926	1703927	1703923	1703924	1703925	1703928	1705921
12									
13	1701644	1701644	1701644	1701644	1701644	1701644	1701644	1701644	1701644
14									
15		1705828	1703980	1703981	1703983	1703984	1703982	1703985	1705828
16	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277
17								1704008	

Table 4-3. M450AJ Decal Legend

ltem #	ANSI 1001178362-D	Aus 1001178377-E	Japanese 1001178371-D	Korean 1001178373-D	Eng/ Spanish 1001178367-D	Eng/ French 1001178365-D	Chinese 1001178375-D	Spa/ Portuguese 1001178369-D	CE 1001190004-C
18									
19									
20					3251243	3251243	3251243	3251243	
21									
22	1701691	1701691	1701691	1701691	1701691	1701691	1701691	1701691	1701691
23	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864	1001104864
24	1702868				1704001	1704000		1704002	
25	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949	1001193949	1001173577	1001193949
26	1001196811				1001196811	1001196811		1001196811	
27	1704446	1706378	1704417	1704418	1704454	1704452	1704419	1704453	1706378
28	1704431	1704431	1704431	1704431	1704431	1704431	1704431	1704431	1704431
29									
30									
31									
32									
33									
34									
35									

Table 4-3. M450AJ Decal Legend

ltem #	ANSI 1001178362-D	Aus 1001178377-E	Japanese 1001178371-D	Korean 1001178373-D	Eng/ Spanish 1001178367-D	Eng/ French 1001178365-D	Chinese 1001178375-D	Spa/ Portuguese 1001178369-D	CE 1001190004-C
36									
37	1701500	1703811	1701500	1701500	1701500	1701500	1701500	1701500	1703811
38	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509
39	1703813	1705670	1704342	1704343	1704339	1704340	1704344	1704341	1705670
40	3252347								
41	1703804	1701518	1703950	1703951	1703947	1703948	1703949	1703952	1701518
42									
43									
44									
45									
46									
47	1702265	1705977	1702271	1703987	1702265	1702265	1703988	1703991	1705977
48									
49									
50	1702300	1703814	1702300	1702300	1702300	1702300	1702300	1702300	1703814
51									
52	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631
53	1001121814	1705978	1001121821	1001121921	1001121818	1001121816	1001121823	1001121923	1705978

Table 4-3. M450AJ Decal Legend

ltem #	ANSI 1001178362-D	Aus 1001178377-E	Japanese 1001178371-D	Korean 1001178373-D	Eng/ Spanish 1001178367-D	Eng/ French 1001178365-D	Chinese 1001178375-D	Spa/ Portuguese 1001178369-D	CE 1001190004-C
54									
55									
56									
57									
58									
59									
60									
61									
62									
63									
64	1706950	1706950			1706950	1706950		1706950	
65	1001121801	1705978	1001121808	1001121918	1001121805	1001121803	1001121810	1001121920	1705978
66	1701502	1701502	1701502						
67	1701503	1701503	1701503						
68									
69									
70	1704286	1704286	1001093687	1001093687	1704371	1001093687	1001093687	1001093687	1001093687
71									

Table 4-3. M450AJ Decal Legend

ltem #	ANSI 1001178362-D	Aus 1001178377-E	Japanese 1001178371-D	Korean 1001178373-D	Eng/ Spanish 1001178367-D	Eng/ French 1001178365-D	Chinese 1001178375-D	Spa/ Portuguese 1001178369-D	CE 1001190004-C
72									
73	1702962								
74									
75			1705084						
76									
77	1704412	1704412	1704412	1704412	1704412	1704412	1704412	1704412	1704412
78	1001121510	1001121510	1001121510	1001221510	1001121510	1001121510	1001121510	1001121510	1001121510
79	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885
80									
81	1705351	1705351	1705426	1705427	1705910	1705429	1705430	1001113680	
82	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882	1001189882

NOTES:	
	·

## **SECTION 5. EMERGENCY PROCEDURES**

## 5.1 GENERAL

This section explains the steps to be taken in case of an emergency situation while operating.

### 5.2 INCIDENT NOTIFICATION

JLG Industries, Inc. must be notified immediately of any incident involving a JLG product. Even if no injury or property damage is evident, the factory should be contacted by telephone and provided with all necessary details.

In USA: JLG Phone: 877-JLG-SAFE (554-7233) (8am till 4:45pm EST)

Outside USA:

240-420-2661

E-mail:

ProductSafety@JLG.com

Failure to notify the manufacturer of an incident involving a JLG Industries product within 48 hours of such an occurrence may void any warranty consideration on that particular machine.

## NOTICE

FOLLOWING ANY ACCIDENT, THOROUGHLY INSPECT THE MACHINE AND TEST ALL FUNCTIONS FIRST FROM THE GROUND CONTROLS, THEN FROM THE PLATFORM CON-TROLS. DO NOT LIFT ABOVE 3 M (10 FT.) UNTIL YOU ARE SURE THAT ALL DAMAGE HAS BEEN REPAIRED, IF REQUIRED, AND THAT ALL CONTROLS ARE OPERATING COR-RECTLY.

## 5.3 EMERGENCY OPERATION

## **Operator Unable to Control Machine**

IF THE PLATFORM OPERATOR IS PINNED, TRAPPED OR UNABLE TO OPERATE OR CONTROL MACHINE:

- 1. Other personnel should operate the machine from ground controls only as required.
- 2. Other qualified personnel on the platform may use the platform controls. DO NOT CONTINUE OPERATION IF CONTROLS DO NOT FUNCTION PROPERLY.
- **3.** Cranes, forklift trucks or other equipment can be used to remove platform occupants and stabilize motion of the machine.

## **Platform or Boom Caught Overhead**

If the platform or boom becomes jammed or snagged in overhead structures or equipment, rescue platform occupants prior to freeing the machine.

## 5.4 EMERGENCY TOWING PROCEDURES

Towing this machine is prohibited, unless properly equipped. However, provisions for moving the machine, in case of a malfunction or power failure, have been incorporated. The following procedures are to be used ONLY for emergency movement to a suitable maintenance area.

- **1.** Chock wheels securely.
- 2. Disengage drive hubs by reversing disconnect caps.
- **3.** Connect suitable equipment, remove chocks, and move machine.

After moving machine, complete the following procedures:

- 1. Position machine on a firm and level surface.
- **2.** Chock wheels securely.
- 3. Engage drive hubs by reversing disconnect caps on hubs.
- 4. Remove chocks from wheels as needed.

## 5.5 MANUAL DESCENT SYSTEM

The manual descent system is used, in the event of total power failure, to lower the upper and lower booms using gravity. To operate the manual descent system, proceed as follows:

- 1. Locate manual descent knob on main valve and turn clockwise. Install handle into manual descent pump and lower the Mid and Lower Booms by pumping the handle until they are completely lowered.
- **2.** Turn manual descent knob counterclockwise and lower the Upper (or main) Boom by pumping the handle until it is completely lowered. Return manual descent knob to center position and stow handle in bracket provided.

## 5.6 MANUAL SWING OVERRIDE

The manual swing override is used to manually swing boom and turntable assembly in the event of a total power failure when the platform is positioned over a structure or obstacle. To operate the manual swing override, proceed as follows:

- 1. Using a 7/8 inch socket and ratchet wrench, locate nut on swing worm gear on left side of machine.
- 2. Install wrench on nut and ratchet in the direction desired.

## 5.7 MACHINE SAFETY SYSTEM OVERRIDE (MSSO)(CE ONLY)

The Machine Safety System Override (MSSO) is only to be used to retrieve an operator that is pinned, trapped, or unable to operate the machine and function controls are locked out from the platform due to a platform overload situation.



- **NOTE:** If the MSSO functionality is used, the fault indicator will flash and a fault code is set in the JLG Control System which must be reset by a qualified JLG Service Technician.
- **NOTE:** No functional checks of the MSSO system are necessary. The JLG Control system will set a Diagnostic Trouble Code if the control switch is faulty.

To operate the MSSO:

- 1. From the ground control console, place the Platform/ Ground Select switch in the Ground position.
- 2. Pull out the Power/Emergency Stop control.
- 3. Start the engine.
- **4.** Press and hold the MSSO switch and the control switch for the desired function.

### **SECTION 5 - EMERGENCY PROCEDURES**

NOTES:	

## **SECTION 6. ACCESSORIES**

	Market						
Accessory	ANSI (USA Only)	ANSI	CSA	Œ	AUS	Japan	China
Soft Touch	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
Fall Arrest Platform (36x60)		$\checkmark$					
Fall Arrest Platform (36x72)	$\checkmark$		$\checkmark$			$\checkmark$	
Pipe Racks	$\checkmark$						

#### **Table 6-1. Available Accessories**

### 6.1 SOFT TOUCH

A padding kit is mounted to the platform rails and to a frame suspended below the platform. Limit switches deactivate platform functions when the padded framework contacts an adjacent structure. A button on the platform console allows override of the system.




Figure 6-1. Soft Touch

### 6.2 FALL ARREST PLATFORM

6.3 PIPE RACKS


**NOTE:** Refer to JLG External Fall Arrest System manual (P/N-3128935) for more detailed information.

The external fall arrest system is designed to provide a lanyard attach point while allowing the operator to access areas outside the platform. Exit/Enter the platform through the gate area only. The system is designed for use by one person.

Personnel must use fall protection at all times. A full body harness is required with lanyard not to exceed 6 ft. (1.8 M) in length, that limits the maximum arrest force to 900 lbs. (408 kg) for the transfastener type and 1350 lbs. (612 kg) for the shuttle type fall arrest system.



# DO NOT OPERATE ANY MACHINE FUNCTIONS WHILE OUTSIDE OF PLATFORM. BE CAREFUL WHEN ENTERING/EXITING THE PLATFORM AT ELEVATION.



Pipe Racks provide a way to store pipe or conduit inside the platform in order to prevent rail damage and optimize platform utility. This accessory consists of two racks with adjustable straps to secure the load in place.

### **Safety Precautions**

## **WARNING**

REDUCE PLATFORM CAPACITY BY 100 LBS (45.5 KG) WHEN INSTALLED.

## **WARNING**

#### WEIGHT IN RACKS PLUS WEIGHT IN PLATFORM MUST NOT EXCEED RATED CAPACITY.

## NOTICE

# THE MAXIMUM LOAD IN THE RACKS IS 180 LBS (80 KG) EVENLY DISTRIBUTED BETWEEN THE TWO RACKS.

## NOTICE

### THE MAXIMUM LENGTH OF MATERIAL IN RACKS IS 20 FT (6.1 M).

- Ensure no personnel are beneath the platform.
- Do not exit platform over rails or stand on rails.
- Do not drive machine without material secured
- Return racks to the stowed position when not in use.
- Use this option only on approved models.

## **Preparation and Inspection**

- Ensure racks are secured to the platform rails.
- Replace torn or frayed tie-down straps.

## **Operation**

- 1. To prepare racks for loading, remove locking pins, rotate each rack 90 degrees from stowed to working position, then secure with locking pins.
- 2. Loosen and remove tie-down straps. Place material on racks with weight evenly distributed between both racks.
- **3.** Route the tie-down straps at each end across loaded material and tighten.
- **4.** To remove material, loosen and remove tie-down straps, then carefully remove material from racks.
- **NOTE:** Reinstall tie-down straps across any remaining material before continuing machine operations.

## **SECTION 7. GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

### 7.1 INTRODUCTION

This section of the manual provides additional necessary information to the operator for proper operation and maintenance of this machine.

The maintenance portion of this section is intended as information to assist the machine operator to perform daily maintenance tasks only, and does not replace the more thorough Preventive Maintenance and Inspection Schedule included in the Service and Maintenance Manual.

#### **Other Publications Available:**

Service and Maintenance Manual	l3121714
--------------------------------	----------

Illustrated Parts Manual	715
--------------------------	-----

### 7.2 OPERATING SPECIFICATIONS

#### **Table 7-1. Operating Specifications**

500 lb. (227 kg)
500 lb. (230 kg)
3.2 mph (5.2 kph)
30%
5°
6 ft. 6.25 in. (1.9 m) 6 ft. 7 in. (2.0 m)
23 ft. 1in.(7.0 m) 23 ft. 9 in. (7.2 4 m)
15 ft. 3 in. (4.65 m)
2 ft. (0.61 m)

### **SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

Table 7-1. Operating Specifications

## Capacities

Table 7-2. Capacities

Generator Fuel Tank	4 Gallons (15.1 L)	
Hydraulic Oil Tank	5 Gallons (19L) w/ 10% air space	
Hydraulic System (Including Tank)	9 Gallons (34.1 L)	
Torque Hub, Drive <sup>*</sup>	25.5 ounces (0.75 L)	
*Torque hubs should be one half full of lubricant.		

Maximum Tire Load:	
E450A	6100 lbs. (2,767 kg)
M450AJ, E450AJ	6900 lbs. (3,130 kg)
Ground Bearing Pressure	
E450A	64 psi (4.5 kg/cm <sup>2</sup> )
M450AJ, E450AJ	75 psi (5.2 kg/cm <sup>2</sup> )
System Voltage	48 volts
Battery Life per Charge	7 hours continuous
Battery Recharge Time	
Charger	17 hours from full discharge
Generator	6.2 hours
Gross Machine Weight (Platform Empty)	
E450A	13,100 lb. (5942 kg)
E450AJ/M450AJ	15,100 lb. (6804 kg)

### Tires

#### **Table 7-3. Tire Specifications**

Size	IN240/55-17.5	IN240/55-17.5	26x7x20
Load Range	E	E	N/A
<b>Ply Rating</b>	10	10	N/A
Tire Pressure	90 psi (6.2 Bar)	Foam-Filled	Solid

### **Dimensional Data**

#### Table 7-4. Dimensional Data

Machine Length (stowed) E450A M450AJ, E450AJ	18ft. 8.0 in. (5.69 m) 21ft. 2 in. (6.45 m)
Up and Over Platform Height E450A M450AJ, E450AJ	24 ft. 7 in. (7.49 m) 25 ft. 3 in. (7.7 m)
Horizontal Reach @ Maximum Up and Over E450A M450AJ, E450AJ	23 ft. 1 in. (7.0 m) 23 ft. 9 in. (7.24 m)
Machine Width	5 ft. 9 in. (1.75 m)

Table 7-4. Dimensional Data

Wheel Base	6 ft. 7.0 in. (2.00 m)
Working Height	51 ft. 0 in. (15.54 m)
Platform Height	45 ft. 0 in. (13.72 m)
Track Width	5 ft. 0 in. (1.51 m)
Tail Swing (Any Position)	0
Ground Clearance E450A M450AJ, E450AJ	8.5 in. (0.22 m) 8 in. (0.20 m)

## **Torque Specifications**

Table 7-5. Torque Requirements

Description	Torque Value	Interval Hours
Wheel Lugs	170 ft. lbs. (230 Nm)	150
Swing Bearing ((Loctite)	190 ft. lbs. (260 Nm)	50/600*

\* Check swing bearing bolts for security after first 50 hours of operation and every 600 hours thereafter.

## Hydraulic Oil

Table 7-6. Hydraulic Oil

Hydraulic System Operating Temperature Range	S.A.E. Viscosity Grade
+0° to + 180° F (-18° to +83° C)	10W
+0° to + 210° F (-18° to +99° C)	10W-20, 10W30
+50° to + 210° F (+10° to +99° C	20W-20

**NOTE:** Hydraulic oils must have anti-wear qualities at least to API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service.

Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. If use of hydraulic oil other than Mobil DTE 10 is desired, contact JLG Industries for proper recommendations.

### Table 7-7. Mobil DTE 10 Excel 15 Specs

ISO Viscosity Grade	#15		
Pour Point, Max	-65°F (-54°C)		
Flash Point, Min.	360°F (182°C)		
Viscosity			
at 40°C	15.8 <i>c</i> St		
at 100°C	4.07 cSt		
at 100°F	15.8cSt		
at 212°F	4.07 cSt		
Viscosity Index	168		
Density (Kg/I) @ 15°C	0.8375		
Density (lb/in3) @60° F	0.0302		

#### Table 7-8. Mobil EAL 224H Specs

Туре	Synthetic Biodegradable		
ISO Viscosity Grade	32/46		
Specific Gravity	.922		
Pour Point, Max	-25°F(-32°C)		
Flash Point, Min.	428°F (220°C)		
Operating Temp.	0 to 180°F (-17 to 162°C)		
Weight	7.64 lb. per gal. (0.9 kg per liter)		
Viscosity			
at 40°C	37 cSt		
at 100°C	8.4cSt		
Viscosity Index	213		
<b>NOTE:</b> Must be stored above 32°F (14°C)			

## **Critical Stability Weights**

Table 7-9. Critical Stability Weights


Component	LB.	KG.
Counterweight	3850	1746
Tire & Wheel (foam-filled)	207	94
Platform (4ft [1.2 m])	90	41
Platform (5 ft [1.5 m])	100	45
Battery (each)	120	54



DO NOT REPLACE ITEMS CRITICAL TO STABILITY WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION (FOR EXAMPLE: BATTERIES, FILLED TIRES, PLATFORM) DO NOT MODIFY UNIT IN ANY WAY TO AFFECT STABILITY.


## **Serial Number Locations**

For machine identification, a serial number plate is affixed to the left rear of frame, in front of left rear wheel. If the serial number plate is damaged or missing, the machine serial number is stamped on the top left side of the frame and the top left side of the turntable. In addition, the serial number is stamped on top of the end of the upper boom, mid boom, and lower boom at the left rear of the booms.




**Figure 7-1. Serial Number Locations** 

# SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE



### **SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**



## 7.3 MAINTENANCE AND LUBRICATION

**NOTE:** The following numbers correspond to those in Figure 7-2. and Figure 7-3.

#### **Table 7-10. Lubrication Specifications**

KEY	SPECIFICATIONS
MPG	Multipurpose Grease having a minimum dripping point of 350 degrees F. Excellent water resistance and adhesive qualities; and being of extreme pressure type (Timken OK 40 pounds minimum).
EPGL	Extreme Pressure Gear Lube (oil) meeting API Service Classification GL-5 or Mil-Spec Mil-L-2105.
HO	Hydraulic Oil. Mobil DTE-10
0G*	Open Gear Lube - Tribol Molub-Alloy 936 Open Gear Compound. (JLG Part No. 3020027)
BG*	Bearing Grease (JLG Part No. 3020029) Mobilith SHA 460.
LL	Synthetic Lithium Lubricant, Gredag 741 Grease. (JLG Part No. 3020022)
EO	Engine (crankcase) Oil. Refer to Engine Operation Manual.
*MPG may be substituted for these lubricants, if necessary, but service intervals will be reduced.	

## NOTICE


LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

1. Swing Bearing

Lube Point(s) - 2 Grease Fittings Capacity - A/R Lube - MPG Interval - Every 3 months or 150 hrs of operation Comments - Remote Access (Optional) 2. Swing Bearing/Worm Gear Teeth



DO NOT OVERGREASE BEARINGS. OVERGREASING BEARINGS WILL RESULT IN BLOW-ING OUTER SEAL IN HOUSING.



Lube Point(s) - Grease Fittings Capacity - Spray On Lube - OG or Mobiltac375NC Interval - A/R Comments - If necessary install grease fittings into worm gear housing and grease bearings.

**NOTE:** OG will allow better cycle times than Mobiltac375NC, however Mobiltac375NC must be used in dusty environments. If the swing function becomes noisy and/or rough lubricate the bearing teeth.

### **SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

3. Hydraulic Tank



Lube Point(s) - Fill Cap Capacity - 4 Gal. (15.1 L)


Lube - HO

Interval - Check Level daily; Change every 2 years or 1200 hours of operation.

Comments - On new machines, those recently overhauled, or after changing hydraulic oil, operate all systems a minimum of two complete cycles and recheck oil level in reservoir.

### **SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

4. Hydraulic Return Filter





Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter.

Comments - Under certain conditions, it may be necessary to replace the hydraulic filter on a more frequent basis. A common symptom of a dirty filter is sluggishness experienced in hydraulic functions.

5. Wheel Drive Hub



Lube Point(s) - Level/Fill Plug Capacity - 17 oz. (1/2 Full) Lube - EPGL Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation 6. Wheel Bearings



- Lube Point(s) Repack Capacity - A/R Lube - MPG Interval - Every 2 years or 1200 hours of operation
- 7. Spindles/Bushing

Capacity - A/R Lube - Lithium Lubricant Interval - Every 2 years or 1200 hours of operation Comments - At Spindle/Bushing Replacement; Coat I.D. of bushings prior to installing king pins.

### **SECTION 7 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

### 8. Boom Pivot Pins/Bushing

Capacity - A/R Lube - Lithium Lubricant Interval - Every 2 years or 1200 hours of operation Comments - At boom pivot pins/bushing replacement; Coat I.D. of bushings prior to installing pivot pins.

#### 9. Engine





Lube Point(s) - Fill Cap Capacity - Refer to Engine Manual Lube - EO Interval - 3 Months or 150 hours of operation Comments - Check level daily/Change in accordance with engine manual.

## 7.4 BATTERY MAINTENANCE AND CHARGING

## Battery Maintenance, Quarterly

1. Open battery compartment cover to allow access to battery terminals and vent caps.

# **A** CAUTION

#### WHEN ADDING WATER TO BATTERIES, ADD WATER UNTIL ELECTROLYTE COVERS PLATES. DO NOT CHARGE BATTERIES UNLESS ELECTROLYTE COVERS THE PLATES.

**NOTE:** When adding distilled water to batteries, non-metallic containers and/or funnels must be used.

To avoid electrolyte overflow, add distilled water to batteries after charging.

When adding water to the battery, fill only to level indicated.

- 2. Remove all vent caps and inspect electrolyte level of each cell. Electrolyte level should be to the ring approximately one inch from top of battery. Fill batteries with distilled water only. Replace and secure all vent caps.
- **3.** Remove battery cables from each battery post one at a time, negative first. Clean cables with acid neutralizing solution

(e.g. baking soda and water or ammonia) and wire brush. Replace cables and/or cable clamp bolts as required.

- **4.** Clean battery post with wire brush then re-connect cable to post. Coat non-contact surfaces with mineral grease or petroleum jelly.
- **5.** When all cables and terminal posts have been cleaned, ensure all cables are properly positioned and do not get pinched. Close battery compartment cover.
- 6. Start hydraulic system and ensure that it functions properly.

# **Optional On Board Generator**

# A WARNING

#### EXHAUST GAS HAZARD. RUN THE GENERATOR IN A WELL VENTILATED AREA ONLY.

# NOTICE

### WHEN THE GENERATOR ENABLE CONTROL LOCATED IN THE PLATFORM CONTROL BOX IS IN THE ON POSITION AND THE GROUND EMERGENCY STOP SWITCH IN ON (PULLED OUT), THE GENERATOR WILL START AUTOMATICALLY WHEN THE BATTERIES REACH A LOW-CHARGE STATE AUTOMATICALLY CHARGING THE BATTERIES.

**NOTE:** The engine will automatically shut down under the following conditions:

High Engine Oil Temperature Low Engine Oil Pressure Engine Overspeed Generator Overvoltage

# **WARNING**

TO AVOID INJURY FROM AN EXPLOSION, DO NOT SMOKE OR ALLOW SPARKS OR A FLAME NEAR BATTERY DURING SERVICING. ALWAYS WEAR EYE AND HAND PROTEC-TION WHEN SERVICING BATTERIES.

# Battery Charging (On Board Charger)

- 1. For maximum battery life:
  - a. Avoid completely discharging the batteries.
  - **b.** Fully charge the batteries each day the machine is used.
  - **c.** Charge the batteries at available times between charging.
  - **d.** If applicable, be sure the battery fluid covers the battery plates before charging, but to avoid overflow, do not top off the fluid level until charging.
  - 2. To charge the batteries, connect the charger to an appropriate volt source with a 15 amp minimum capacity.
  - **3.** The charge cycle is complete when the green 100% charge light on the battery charger comes on.

# 7.5 TIRES & WHEELS

## **Tire Inflation**

The air pressure for pneumatic tires must be equal to the air pressure that is stenciled on the side of the JLG product or rim decal for safe and proper operational characteristics.

## **Tire Damage**

For pneumatic tires, JLG Industries, Inc. recommends that when any cut, rip, or tear is discovered that exposes sidewall or tread area cords in the tire, measures must be taken to remove the JLG product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- a smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length
- any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction
- any punctures which exceed 1 inch in diameter

· any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to insure the damage has not propagated beyond the allowable criteria.

## **Tire Replacement**

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the JLG Parts Manual for the part number of the approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original
- Wheel diameter, width, and offset dimensions equal to the original
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load)

Unless specifically approved by JLG Industries Inc. do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. When selecting and installing a replacement tire, ensure that all tires are inflated to the pressure recommended by JLG. Due to size variations between tire brands, both tires on the same axle should be the same.

## **Wheel Replacement**

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

## **Wheel Installation**

It is extremely important to apply and maintain proper wheel mounting torque.


# **WARNING**

### WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.

2. Tighten nuts in the following sequence:



**3.** The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

Table 7-11.	Wheel Tor	que Chart
-------------	-----------	-----------

TORQUE SEQUENCE			
1st Stage	2nd Stage	3rd Stage	
40 ft. lbs. (55 Nm)	100 ft. lbs. (130 Nm)	170 ft. lbs. (255 Nm)	

4. Wheel nuts should be torqued after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

# 7.6 SUPPLEMENTAL INFORMATION

The following information is provided in accordance with the requirements of the European Machinery Directive 2006/42/EC and is only applicable to CE machines.

For electric powered machines, the equivalent continuous A-Weighted sound pressure level at the work platform is less than 70dB(A)

For combustion engine powered machines, guaranteed Sound Power Level (LWA) per European Directive 2000/14/EC (Noise Emission in the Environment by Equipment for Use Outdoors) based on test methods in accordance with Annex III, Part B, Method 1 and 0 of the directive, is 104 dB.

The vibration total value to which the hand-arm system is subjected does not exceed 2,5 m/s<sup>2</sup>. The highest root mean square value of weighted acceleration to which the whole body is subjected does not exceed 0,5 m/s<sup>2</sup>.

# **SECTION 8. INSPECTION AND REPAIR LOG**

Machine Serial Number\_\_\_\_\_

#### Table 8-1. Inspection and Repair Log

Date	Comments

### **SECTION 8 - INSPECTION AND REPAIR LOG**

Table 8-1. Inspection and Rep	pair Log
-------------------------------	----------

Date	Comments





An Oshkosh Corporation Company

Corporate Office JLG Industries, Inc. 1 JLG Drive McConnellsburg, PA 17233-9533 USA (717) 485-5161 (Corporate) (877) 554-5438 (Customer Support) (717) 485-6417

Visit our website for JLG Worldwide Locations www.jlg.com